

This document provides installation instructions for mounting the 7005 controller in a two-post 19-inch Telco rack.

### Package Contents

- Rack mount tray
- Four M3 x 5 mm flat head screws
- Four M6 x 15 mm Phillips pan head screws
- Aruba 7005-MNT-19 Kit Installation Guide (this document, printed)

### Rack Mount Installation

This mounting option allows mounting the 7005 controller in a two-post 19-inch Telco rack.

#### Required Tools and Equipment

The following tools and equipment are required for installing a 7005 controller:

- Rack mount tray (x1) for rack mount installation
- M3 x 5 mm flat head screws (x4) for securing the controller on the rack mount tray
- M6 x 15 mm Phillips pan head screws (x4) for rack mount
- Suitable screwdrivers for all screw types provided in the box (not included in the kit)



---

Some racks require screws that differ from those included with the 7005 controller accessory kit. Ensure that you have the correct screws before installing the 7005 controller.


---

#### Installation Steps


To install a 7005 controller into a two post 19-inch rack:

1. Route and secure the DC power cable correctly into the slot provided at the bottom of the controller. See [Figure 1](#).
2. Place the controller on the rack mount tray such that the DC cable is not obstructed. See [Figure 2](#).

**Figure 1** DC Cable Routing Slot




**Figure 2** DC Cable and Rack Mount Tray




3. Turn the rack mount tray up side down to align the controller with the screw holes on the tray. Secure the controller with four M3 x 5 mm flat head screws using a suitable screwdriver. See [Figure 3](#).

**Figure 3** *Controller Installation on the Tray*



4. Mount the rack mount tray within the two-post 19-inch rack using four M6 x 15 mm Phillips pan head screws and a suitable screwdriver. See [Figure 4](#).

**Figure 4** *Rack Mount Installation*



Rack mount installation of a 7005 controller is now complete.

# Contacting Support

**Table 1** *Contact Information*

Main Site	<a href="http://arubanetworks.com">arubanetworks.com</a>
Support Site	<a href="http://support.arubanetworks.com">support.arubanetworks.com</a>
Airheads Social Forums and Knowledge Base	<a href="http://community.arubanetworks.com">community.arubanetworks.com</a>
North American Telephone	1-800-943-4526 (Toll Free) 1-408-754-1200
International Telephones	<a href="http://www.arubanetworks.com/support-services/support-program/contact-support">http://www.arubanetworks.com/support-services/support-program/contact-support</a>
Software Licensing Site	<a href="http://licensing.arubanetworks.com">licensing.arubanetworks.com</a>
End of Support information	<a href="http://www.arubanetworks.com/support-services/end-of-life-products/end-of-life-policy/">http://www.arubanetworks.com/support-services/end-of-life-products/end-of-life-policy/</a>
Security Incident Response Team (SIRT)	<a href="http://www.arubanetworks.com/support-services/security-bulletins/">http://www.arubanetworks.com/support-services/security-bulletins/</a>
<b>Support Email Addresses</b>	
Americas, APAC, and EMEA	<a href="mailto:support@arubanetworks.com">support@arubanetworks.com</a>
Security Incident Response Team (SIRT)	<a href="mailto:sirt@arubanetworks.com">sirt@arubanetworks.com</a>

© 2014 Aruba Networks, Inc. All rights reserved.



[www.arubanetworks.com](http://www.arubanetworks.com)

1344 Crossman Avenue  
Sunnyvale, California 94089

Phone: 408.227.4500  
Fax 408.227.4550